



Calibration Tables

Imperial			Metric		
Depth	Pivot	Radius	Depth	Pivot	Radius
7.0	3.0	3.0	180	77	78
7.8	3.4	3.5	200	88	92
8.6	3.8	4.1	220	98	105
9.4	4.3	4.6	240	109	119
10.2	4.7	5.1	260	119	132
11.0	5.1	5.7	280	130	146
11.7	5.5	6.2	300	141	159
12.5	5.9	6.7	320	151	173
13.3	6.4	7.2	340	162	186
14.1	6.8	7.8	360	172	200
14.9	7.2	8.3	380	183	213
15.7	7.6	8.8	400	194	227
16.5	8.0	9.4	420	204	240
17.3	8.5	9.9	440	215	254
18.1	8.9	10.4	460	225	267
18.9	9.3	11.0	480	236	281
19.6	9.7	11.5	500	247	294
20.4	10.1	12.0	520	257	308
21.2	10.6	12.5	540	268	321
22.0	11.0	13.1	560	278	335
22.8	11.4	13.6	580	289	348
23.6	11.8	14.1	600	300	362
24.4	12.2	14.7	620	310	375
25.2	12.7	15.2	640	321	389
26.0	13.1	15.7	660	331	402

Dimensions for 5 and 6 hole flange fittings

Notes:

- Modifications to fuel tanks should only be attempted with the tank removed from the vehicle, emptied, cleaned and dried.
- Recommended aperture diameter in tank 44.0mm (minimum diameter 43.0mm).



RACETECH

Raceparts (UK) Ltd., Unit 3, Rockfort
 Industrial Estate,
 Wallingford, Oxon., OX10 9DA
 Email: sales@raceparts.co.uk
 Tel: +44 (0) 1491 822000

Information for Fuel Senders

Part No.	Description
RTECF6H	Insulated Return, 6 Hole fix, 100ohms empty to 1800ohms full
RTECF5H	Insulated Return, 5 Hole fix, 100ohms empty to 1800ohms full

Fitting Instructions

We recommend you read all instructions and notes prior to beginning installation

CAUTION

Disconnect the Battery Negative Cable Prior to Installation

Measure the internal depth of the fuel tank.

From the table, select pivot dimension and float arm radius against tank depth measured.

Slide the retaining clips and the float onto the flat arm wire and adjust to the correct radius. The clips can be pushed onto, or moved along the wire by squeezing the ends together.

SAFETY PRECAUTION: - Float arm wire is sharp. Take care when handling to prevent injury.

Slide the resistor box onto the rod, ensuring the orientation is as shown in the diagram, and adjust to approximately the correct pivot height. Mark the rod at the bottom of the lower adjusting bracket.

Remove the resistor box and cut off the excess rod below the adjusting bracket with a hacksaw.

Attach the square nut and bolt BUT DO NOT TIGHTEN.

Holding the resistor box, rotate the flange to the correct float arm orientation tightening the wire around the rod so that the wire does not interfere with the operation of the float arm.

Position the resistor box to the correct pivot height and orientation and fully tighten the screws until the surfaces of the adjusting bracket meet and the box is securely fastened to the rod.

Slide the gasket over the float, along the arm, over the resistor box and up to the underside of the flange.

Correctly orientate the gasket. For the five hole variant, position the notch in the gasket opposite the index hole in the fixing plate prior to inserting the unit into the tank.

Install the unit, float first, into the tank and align the screw holes with those on the mounting flange and sealing gasket.

Insert all mounting screws and tighten securely. DO NOT OVERTIGHTEN

Note:

- Prior to installing into tank, connect the gauge and the sender together to check the gauge reads full when the float arm is in the 'full' position and reads empty when the float is in the 'empty' position. (If your gauge is reading in reverse, it is likely that the resistor box has been fitted upside down - please check orientation with diagram).

